QUICKSTART

Puzzi 10/1 - Puzzi 10/2

-***WARNING***

These are only brief instructions! Please read the operating instructions accompanying the appliance prior to using or maintaining the appliance.

The non-compliance with the operating and safety instructions may lead to damage of the appliance and to risks for the operator and other persons.

Start up

1

A



B



C



A Remove the cover of the wastewater tank.
B Remove waste water tank.
C Fill detergent solution into the fresh water reservoir. The fill level must not exceed the "MAX" mark.

Operation

1


A



B



C




Turning on the Appliance

A Plug in the mains plug.
B Press the suction switch to turn on the suction turbine.
C Press the spray switch to switch on the spray pump.

2

A




A Operate the lever on the manifold in order to spray the cleaning solution. Run across the surface to be cleaned in overlapping paths. Pull the nozzle backwards (do not push).
B Press the suction switch to turn on the suction turbine.
C Press the spray switch to switch on the spray pump.

Finish operation

1

A



B




Turn off the appliance

A Switch off the spray and suction switches.
B Pull out the mains plug.

Finish operation

2

A



B



C




Empty wastewater container


A If the dirt water reservoir is full, switch off the suction and spray switches.
B Remove the lid.
C Remove the wastewater container from the appliance and drain it.

3


A




B



C



D





Empty the fresh water reservoir

A Turn off the appliance.
B Shortly activate the lever on bender to decrease the pressure.
C Separate bender from the spray/suction hose.
Insert the suction hose into the fresh water reservoir.
D Press the suction switch to turn on the suction turbine.

4


A



B



C



After each operation

A Flush appliance.
B Empty the wastewater container and clean it under running water.
C Empty the fresh water reservoir.
Suck the remaining fresh water out of the tank.
D Clean the outside of the appliance with a damp cloth.
E Remove all water from the appliance prior to longer periods of non-use to avoid offensive odours.
F Allow appliance to dry thoroughly:
Remove or move lid sideways.

6

A



Transport

A For transport, place suction pipe on the carrying handle and place the spray/suction hose on top of the appliance.
Wind up the mains cable and hook it into the cable hook.